PART NO.	ATA/CMM	MANUFACTURER	COMPONENT NAME
0331201960 INSPECT ONLY	49-26-31	AERONAMIC	GEAR RING, IGV
0332220960 INSPECT ONLY	APS3200 CIR	P&WC	SUPPORT, IGV ACTUATOR
10198 REPAIR ONLY	RS-101000	TAVIS	TRANSDUCER
10198-1 REPAIR ONLY	RS-101000	TAVIS	TRANSDUCER
10198-BSC REPAIR ONLY	RS-101000	TAVIS	TRANSDUCER
102-00000 INSPECT/TEST ONLY	31-00-02	NORWICH AERO	TEMPERATURE SENSOR
10-369510-1	03-5NA-44	NAVAIR	EXCITER
10-369510-2	03-5NA-44	NAVAIR	EXCITER
10-378400-3 868962-2	74-10-06	UNISON HONEYWELL	EXCITER
10-378400-5 868962-3	74-10-06	UNISON HONEYWELL	EXCITER
10-381175-10 3603281-8 TEST ONLY	49-40-33	UNISON HONEYWELL	EXCITER
10-381175-2 378640 TEST ONLY	49-40-33	UNISON HONEYWELL	EXCITER
10-381175-3 3603281-3 TEST ONLY	49-40-33	UNISON HONEYWELL	EXCITER
10-381175-4 3603281-4 TEST ONLY	49-40-33	UNISON HONEYWELL	EXCITER
10-381175-6 3603281-3 TEST ONLY	49-40-33	UNISON HONEYWELL	EXCITER
10-381175-7 3603281-4 TEST ONLY	49-40-33	UNISON HONEYWELL	EXCITER
10-381175-9 3603281-7 TEST ONLY	49-40-33	UNISON HONEYWELL	EXCITER
10-381200-7 10-381200-9 3603281-1	49-40-35	UNISON HONEYWELL	EXCITER
10-381550-1 3014365	74-10-42 PMP- JP00414-2	P&WC UNISON	EXCITER
10-381550-2 3035546	74-10-42 PMP- JP00414-2	P&WC UNISON	EXCITER
10-381550-22 3119450-01	74-10-42 PMP- JP00414-2	P&WC UNISON	EXCITER
10-381550-4 3035589	74-10-42 PMP- JP00414-2	P&WC UNISON	EXCITER
10-381550-5 3900106	74-10-42 PMP- JP00414-2	P&WC UNISON	EXCITER
10-381750-1 899580-1	49-40-37	UNISON HONEYWELL	EXCITER
10-381750-12 369256-1	49-40-37	UNISON HONEYWELL	EXCITER
10-381750-14 3603281-6	49-40-37	UNISON HONEYWELL	EXCITER
10-381750-2 369256	49-40-37	UNISON HONEYWELL	EXCITER
10-381750-6 10-381750-10 3603281-2	49-40-37	UNISON HONEYWELL	EXCITER
10-383225-1 1-300-363-03 TEST ONLY	L-1106	UNISON HONEYWELL	EXCITER

	10-383847	49-40-37	UNISON	HOUSING											
	10-387125-2 969690-2	49-41-01	UNISON HONEYWELL	EXCITER											
	10-392000-1 3070378-1	74-10-38	UNISON HONEYWELL	EXCITER											
	10-392000-2 3070378-2	74-10-38	UNISON HONEYWELL	EXCITER											
	10-392119 TEST ONLY	74-10-38	UNISON	CAPACITOR AND DIODE ASSY											
	10-397183	49-40-37	UNISON	CHASSIS											
	10-516000-1 3888000-2 TEST ONLY	49-40-39	UNISON HONEYWELL	EXCITER											
	10-516000-3 3888000-3 TEST ONLY	49-40-39	UNISON HONEYWELL	EXCITER											
	10-614237 TEST ONLY	74-10-06	UNISON HONEYWELL	POWER TRANSFORMER											
	10-614500-1 780524	74-11-03	UNISON P&WC	EXCITER											
	10-614950-1 6899093 TEST ONLY	74-10-05	UNISON ROLLS-ROYCE	EXCITER											
	10-617075-5 3888058-3	49-41-09	UNISON HONEYWELL	EXCITER											
	10-617075-6 3888058-5	49-41-09	UNISON HONEYWELL	EXCITER											
	10-617980-1 9238M66P05 TEST ONLY	74-11-12 PMP- JP00155-5	UNISON GE/CFMI	EXCITER											
	10-621630-1 50T241	74-11-04	UNISON P&WC	EXCITER											
	10-631045-1 9238M66P07 TEST ONLY	74-11-12 PMP- JP00155-5	UNISON GE/CFMI	EXCITER											
	10-631045-2 9238M66P08	74-11-12 PMP- JP00155-5	UNISON GE/CFMI	EXCITER											
	10-631045-3 9238M66P11 TEST ONLY	74-11-12 PMP- JP00155-5	UNISON GE/CFMI	EXCITER											
	117500-29 INSPECT ONLY	49-53-67	HONEYWELL	DIAPHRAGM ASSY											
	14330-004C1	38-34-30	SAFRAN	VACUUM TOILET											
	14330-004C2	38-34-30	SAFRAN	VACUUM TOILET											
	14330-004C3	38-34-30	SAFRAN	VACUUM TOILET											
	14330-004C4	38-34-30	SAFRAN	VACUUM TOILET											
	14403-004	38-34-46	ZODIAC AEROSPACE	LEVEL SENSOR											
	158935-1	49-94-06	HONEYWELL	OIL TEMP CONTROL VALVE											
	158935-2	49-94-06	HONEYWELL	OIL TEMP CONTROL VALVE											
	158935-3	49-94-06	HONEYWELL	OIL TEMP CONTROL VALVE											
	160192-1 TEST ONLY	49-91-18	HONEYWELL	AIR TO OIL COOLER											
	160426-2 TEST ONLY	49-94-40	HONEYWELL	AIR TO OIL COOLER											
	160544-1 INSPECT/TEST ONLY	APS3200 CIR 49-42-09	P&WC	IGNITOR											
	160550-1	49-94-30	HONEYWELL	VALVE TEMPERATURE CONTROL											
	16204-001	38-33-02	MONOGRAM SYSTEMS	MOTOR-PUMP- FILTER ASSEMBLY											
	16204-002	38-33-02	MONOGRAM SYSTEMS	MOTOR-PUMP- FILTER ASSEMBLY											

	16204-003	38-33-02	MONOGRAM SYSTEMS	MOTOR-PUMP-FILTER ASSEMBLY												
	171816-100 TEST ONLY	49-70-02	P&WC	ENGINE SERIAL NUMBER IDENTIFICATION ASSY												
	1A081-0155-1	25-41-18	YOKOHAMA	FLUSH TIMER SWITCH												
	2000866-2 INSPECT/TEST ONLY	49-41-08	HONEYWELL	STARTER												
	2000866-3	49-41-08	HONEYWELL	STARTER												
	2000866-4	49-41-08	HONEYWELL	STARTER												
	232T4BT	49-25-95	HONEYWELL	VALVE												
	2684752 INSPECT ONLY	49-30-99	HONEYWELL	RESOLVER AND LEVER												
	2684816 INSPECT ONLY	49-30-99	HONEYWELL	VALVE												
	2684837-040 INSPECT/TEST ONLY	49-30-99	HONEYWELL	TEMPERATURE PROBE ASSY												
	2684983 INSPECT/TEST ONLY	49-30-99	HONEYWELL	SOLENOID VALVE												
	2685841 INSPECT ONLY	49-30-99	HONEYWELL	FUEL CONTROL HOUSING												
	2704458-1	49-41-14	HONEYWELL	ENGINE STARTER MOTOR												
	2718834 INSPECT/TEST ONLY	49-30-99	HONEYWELL	METERING VALVE												
	3032167 49930 TEST ONLY	74-10-01	P&WC UNISON	EXCITER												
	3038137 9047840-1 TEST ONLY	74-12-04	P&WC UNISON	EXCITER												
	3040032 9047840-2 TEST ONLY	74-12-04	P&WC UNISON	EXCITER												
	3041641-01 9049770-3	74-12-08	P&WC UNISON	EXCITER												
	304300-2 TEST ONLY	49-90-57 49-26-85	HONEYWELL	PRESSURE SWITCH												
	304634-2	49-26-11	HONEYWELL	IGNITOR PLUG												
	305766-1 CH31769 TEST/INSPECT ONLY	49-26-85	HONEYWELL CHAMPION	IGNITOR PLUG												
	305766-4 TEST/INSPECT ONLY	49-26-85	HONEYWELL	IGNITOR PLUG												
	3071949-10	79-20-03	HONEYWELL	LUBE/SCAV PUMP												
	3071949-X	79-20-03	HONEYWELL	LUBE PUMP ASSY												
	3103235-11	73-10-19	HONEYWELL	FUEL NOZZLE												
	3103235-9	73-10-19	HONEYWELL	FUEL NOZZLE												
	3-1285-200 TEST ONLY	49-93-61	HONEYWELL	LOW OIL LEVEL SWITCH												
	3163812-10	49-53-67	HONEYWELL	GUIDE VALVE												
	3169756-4 INSPECT ONLY	49-53-67	HONEYWELL	BODY VALVE ASSEMBLY												
	3169759-6 INSPECT ONLY	49-50-87	HONEYWELL	ACTUATOR												
	3169772-6 INSPECT ONLY	49-53-67	HONEYWELL	HOUSING ASSEMBLY												

	3173837-3	49-53-67	HONEYWELL	RETAINER ASSEMBLY													
	3174726-5	49-53-67	HONEYWELL	FILTER ASSEMBLY													
	319974-1-1	79-20-06	GARRETT	SOLENOID VALVE													
	319974-4-1	79-20-06	GARRETT	SOLENOID VALVE													
	3290476-5 OVERHAUL ONLY	49-50-95	HONEYWELL	SURGE VALVE													
	3290594-1	49-26-51	HONEYWELL	VARIABLE VALVE CHAMBER													
	3291214-2	49-52-29	HONEYWELL	APU BLEED AIR VALVE, 3.5"													
	3291238-2	49-52-31	HONEYWELL	SURGE VALVE													
	3291432-2	49-52-35	HONEYWELL	OUTLINE VALVE													
	3511-004	38-33-02	MONOGRAM SYSTEMS	MOTOR-PUMP-FILTER ASSEMBLY													
	3601193-ALL	49-30-38	HONEYWELL	FUEL ATOMIZER ASSEMBLY													
	3601520-5	49-31-13	HONEYWELL	PRIMARY FUEL ATOMIZER													
	3603357-3	49-26-53 IRM	HONEYWELL	STARTER MOTOR													
	3605812-ALL	49-40-01	HONEYWELL	ELECTRICAL ENGINE STARTER													
	3612120-1 INSPECT ONLY	49-23-49	HONEYWELL	CLUTCH ADAPTER ASSY													
	3612844-1 3612844-2 DISASSEMBLE ONLY	49-23-49	HONEYWELL	STARTER CLUTCH ASSEMBLY													
	3613703-1 INSPECT ONLY	49-23-49	HONEYWELL	ROLLER BEARING													
	3614295-3	49-50-04	HONEYWELL	BUTTERFLY VALVE													
	3614408-1 INSPECT ONLY	49-51-93	HONEYWELL	FLOW SENSOR ASSEMBLY													
	3614409-1 INSPECT ONLY	49-51-93	HONEYWELL	HOUSING ASSEMBLY													
	3614416-1 3614416-2 DISASSEMBLE ONLY	49-51-71	HONEYWELL	FAN ASSEMBLY													
	3615036-1	49-23-49	HONEYWELL	AIRFLOW SENSOR													
	3615139-1 INSPECT ONLY	49-23-49	HONEYWELL	INLET SCREEN ASSEMBLY													
	3615772-2 INSPECT ONLY	49-25-95	HONEYWELL	CONTAINMENT RING													
	3616959-6 DISASSEMBLE ONLY	49-52-37	HONEYWELL	FAN ASSEMBLY													
	3616959-7	49-52-37	HONEYWELL	COOLING FAN ASSEMBLY													
	3616960-3	49-52-41	HONEYWELL	COOLING FAN ASSEMBLY													
	3616961-2 INSPECT ONLY	49-52-41	HONEYWELL	INLET FAN ASSEMBLY													
	3616965-1 INSPECT ONLY	49-52-41	HONEYWELL	CONTAINMENT SUPPORT													
	3616967-1 INSPECT ONLY	49-52-41	HONEYWELL	FAN ROTOR													
	3616969-2 INSPECT ONLY	49-52-41	HONEYWELL	SEAL RETAINER													

	3616977-3 INSPECT ONLY	49-52-37	HONEYWELL	ROTOR FAM ASSEMBLY												
	3617712-1 INSPECT ONLY	49-23-49	HONEYWELL	BEARING RETAINER												
	3617760-1 INSPECT ONLY	49-26-09	HONEYWELL	BLANKET SET												
	369259-47 TEST ONLY	49-41-05	HONEYWELL	IGNITION LEAD												
	372697-10	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	372697-13	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	372697-15	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	372697-16	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	372697-18-1	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	372697-21-1	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	372697-22	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	372697-24	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	372697-6	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	372697-9	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	373048	49-90-01	ALLIED SIGNAL	PRESSURE RELIEF VALVE ASSY												
	373048-1	49-90-01	ALLIED SIGNAL	PRESSURE RELIEF VALVE ASSY												
	373048-2	49-90-01	ALLIED SIGNAL	PRESSURE RELIEF VALVE ASSY												
	373048-3	49-90-01	ALLIED SIGNAL	PRESSURE RELIEF VALVE ASSY												
	375322-10	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	375322-7	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	375322-8	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	375322-9	49-40-01	ALLIED SIGNAL	ELECTRICAL ENGINE STARTER												
	379580-200	49-90-33	AERO CONTROLEX	OIL PUMP												
	379580-300	49-90-33	AERO CONTROLEX	OIL PUMP												
	379580-650	49-90-33	AERO CONTROLEX	OIL PUMP												
	379580-700	49-90-33	AERO CONTROLEX	OIL PUMP												
	3805051-1 INSPECT ONLY	49-26-85	HONEYWELL	GEARBOX ASSY												
	3810196-1 INSPECT ONLY	49-23-49	HONEYWELL	OIL COOLER FAN INLET SCREEN												
	3810209-2 INSPECT ONLY	49-23-49	HONEYWELL	POWER SECTION INSERT												
	3810448-2 INSPECT ONLY	49-25-95	HONEYWELL	INLET SCREEN ASSEMBLY												
	3810821-5 INSPECT ONLY	49-26-85	HONEYWELL	IGV ASSEMBLY												
	3822068-1 INSPECT ONLY	49-23-49	HONEYWELL	SECOND-STAGE COMPRESSOR ROTOR												
	3822504-2 INSPECT ONLY	49-26-85	HONEYWELL	SHAFT												

	3822635-2 INSPECT ONLY	49-26-85	HONEYWELL	ROTOR SEAL HYDRODYNAMIC												
	3824007-1 INSPECT ONLY	49-25-95	HONEYWELL	ENGINE COMPRESSOR INLET BEARING HOUSING ASSEMBLY												
	3826110-2 INSPECT ONLY	49-23-49	HONEYWELL	DESWIRL ASSEMBLY												
	3826251-2 INSPECT ONLY	49-23-49	HONEYWELL	IGVA MOUNT BRACKET COVER												
	3826755-7 INSPECT ONLY	49-25-95	HONEYWELL	COMPRESSOR HOUSING ASSEMBLY												
	3826756-3 INSPECT ONLY	49-25-95	HONEYWELL	COMPRESSOR HOUSING ASSEMBLY												
	3826826-1 3826826-2 3826826-3 INSPECT ONLY	49-25-95	HONEYWELL	DESWIRL ASSEMBLY												
	3827324-3	49-26-85	HONEYWELL	SUPPORT STATIOARY SEAL AIR												
	3827325-3 INSPECT ONLY	49-26-85	HONEYWELL	DIFFUSER ENGINE COMPRESSOR												
	3827402-3	49-26-85	HONEYWELL	HOUSING DIFFUSER												
	3830070-1	49-31-13	HONEYWELL	SECONDARY FUEL ATOMIZER												
	3830386-3 3830386-6	49-25-95	HONEYWELL	COMBUSTION CHAMBER												
	3830416-1	49-30-01	HONEYWELL	FUEL NOZZLE												
	3830418-1 INSPECT ONLY	49-26-85	HONEYWELL	FUEL NOZZLE AIR SHROUD												
	3840022-4 INSPECT ONLY	49-23-49	HONEYWELL	THIRD-STAGE TURBINE WHEEL												
	3840111-7 INSPECT ONLY	49-25-95	HONEYWELL	THIRD-STAGE TURBINE WHEEL												
	3840294-1 INSPECT ONLY	49-25-95	HONEYWELL	SHAFT QUILL												
	3840310-3 INSPECT ONLY	49-26-85	HONEYWELL	FIRST STAGE TURBINE ROTOR ASSY												
	3844009-1 INSPECT ONLY	49-23-49	HONEYWELL	SECOND-STAGE STATOR SUPPORT												
	3844018-1 INSPECT ONLY	49-23-49	HONEYWELL	THIRD-STAGE STATOR ASSEMBLY												
	3844028-4 INSPECT ONLY	49-23-49	HONEYWELL	TURBINE BEARING SUPPORT ASSEMBLY												
	3844050-2 INSPECT ONLY	49-23-49	HONEYWELL	LABYRINTH SEAL												
	3844408-2 INSPECT ONLY	49-25-95	HONEYWELL	FIRST-STAGE SHROUD SUPPORT												
	3844409-2 INSPECT ONLY	49-25-95	HONEYWELL	HOUSING-PISTON RING												
	3844411-1 INSPECT ONLY	49-25-95	HONEYWELL	ROTOR SEAL CURVIC COUPLING												
	3844433-2 INSPECT ONLY	49-25-95	HONEYWELL	THIRD STAGE TURBINE NOZZLE												
	3844821-1 INSPECT ONLY	49-25-95	HONEYWELL	STATIONARY AIR SEAL												
	3844864-1 INSPECT ONLY	49-26-85	HONEYWELL	STATOR												

	3844904-1 INSPECT ONLY	49-25-95	HONEYWELL	BAFFLE													
	3844922-1 INSPECT ONLY	49-26-85	HONEYWELL	HOUSING ASSY TURBINE BEARING													
	3862552-1 INSPECT ONLY	49-23-49	HONEYWELL	TRANSFER TUBE													
	3862775-3	49-51-81	HONEYWELL	FAN ASSEMBLY													
	3868000-4 INSPECT ONLY	49-25-95	HONEYWELL	SHAFT QUILL													
	3876023-2 TEST ONLY	49-23-49	HONEYWELL	TEMP SWITCH													
	3876024-6 TEST ONLY	49-23-49	HONEYWELL	LOW OIL PRESSURE SWITCH													
	3876027-4 TEST ONLY	49-23-49	HONEYWELL	THERMOCOUPLING													
	3876049-4	49-31-02	HONEYWELL	FUEL SOLENOID VALVE													
	3876049-5	49-31-02	HONEYWELL	FUEL SOLENOID VALVE													
	3876059-2 TEST ONLY	49-23-49	HONEYWELL	OIL LEVEL SWITCH													
	3876086-2	49-23-49	HONEYWELL	FLOW SENSOR ASSEMBLY													
	3876096-1 INSPECT ONLY	49-23-49	HONEYWELL	STATIC FLOW SENSOR ASSEMBLY													
	3876127-1 TEST ONLY	49-25-95	HONEYWELL	SENSOR													
	3876132-X	49-41-19	CHAMPION HONEYWELL	IGNITER LEAD ASSEMBLY													
	3876133-1 TEST ONLY	49-26-51	HONEYWELL	PRESSURE SENSOR													
	3876134-1 TEST ONLY	49-25-95	HONEYWELL	SENSOR													
	3876135-2 TEST ONLY	49-23-49	HONEYWELL	SENSOR DELTA													
	3876144-1 TEST ONLY	49-23-49	HONEYWELL	SENSOR TEMP OIL													
	3876145-2 TEST ONLY	49-25-95	HONEYWELL	HEATER													
	3876166-1	49-91-47	ALLIED SIGNAL	DE-OILING SOLENOID VALVE													
	3876185-2 TEST ONLY	49-31-25	HONEYWELL	VALVE SOLENOID													
	3876186-4	49-25-95	HONEYWELL	LOW OIL PRESSURE SWITCH													
	3876188-2	49-25-95	HONEYWELL	SWITCH													
	3876189-2 TEST ONLY	49-25-95	HONEYWELL	ELECTRONIC CHIP DETECTOR													
	3876191-1	49-25-95	HONEYWELL	TEMP LOAD COMPRESSOR													
	3876197-1 TEST ONLY	49-25-95	HONEYWELL	MOTIONAL TRANSDUCER													
	3876203-1 TEST ONLY	49-25-95	HONEYWELL	OIL TEMPERATURE SENSOR													
	3876219-2 TEST ONLY	49-52-15	KULITE	PRESSURE TRANSDUCER													
	3876223-1 TEST ONLY	49-26-85	HONEYWELL	SPEED SENSOR													
	3876225-2 TEST ONLY	49-26-85	HONEYWELL	INLET PRESSURE SENSOR													
	3876226-1 TEST ONLY	49-26-85	HONEYWELL	TOTAL PRESSURE SENSOR													
	3876227-2 TEST ONLY	49-26-85	HONEYWELL	DIFFERENTIAL PRESSURE SENSOR													

	3876255-2 TEST ONLY	49-26-85	HONEYWELL	LOW OIL PRESSURE SWITCH													
	3876271-1 TEST ONLY	49-26-85	HONEYWELL	THERMOCOUPLE EXHAUST GAS TEMP													
	3876330-2 TEST ONLY	49-93-61	HONEYWELL	LOW OIL LEVEL SWITCH													
	3876379-1 TEST ONLY	49-93-01	HONEYWELL	LOW OIL QUANTITY SWITCH													
	3879005-1	49-26-85	HONEYWELL	CHECK VALVE													
	3880124-1 INSPECT ONLY	49-23-49	HONEYWELL	VENT FITTING													
	3880125-1 INSPECT ONLY	49-23-49	HONEYWELL	OIL TRANSFER TUBE													
	3880130-6	49-91-53	AERO CONTROLEX	LUBE PUMP ASSY													
	3880135-7 INSPECT ONLY	49-91-41	AERO CONTROLEX	HOUSING OIL PUMP													
	3880140-1	49-91-43	AERO CONTROLEX	FLUID PRESSURE REGULATING VALVE ASSEMBLY													
	3880140-2	49-91-43	AERO CONTROLEX	FLUID PRESSURE REGULATING VALVE ASSEMBLY													
	3880140-3	49-91-43	AERO CONTROLEX	FLUID PRESSURE REGULATING VALVE ASSEMBLY													
	3880140-4	49-91-43	AERO CONTROLEX	FLUID PRESSURE REGULATING VALVE ASSEMBLY													
	3880160-3	49-23-49	HONEYWELL	SCAVENGE PUMP													
	3880164-2 INSPECT ONLY	49-23-49	HONEYWELL	SPECIAL FITTING													
	3880190-10	49-91-41	AERO CONTROLEX	LUBE PUMP ASSY													
	3880190-11	49-91-41	AERO CONTROLEX	LUBE PUMP ASSY													
	3880190-13	49-91-41	AERO CONTROLEX	LUBE PUMP ASSY													
	3880190-3	49-91-41	AERO CONTROLEX	LUBE PUMP ASSY													
	3880190-4	49-91-41	AERO CONTROLEX	LUBE PUMP ASSY													
	3880190-5	49-91-41	AERO CONTROLEX	LUBE PUMP ASSY													
	3880190-7	49-91-41	AERO CONTROLEX	LUBE PUMP ASSY													
	3880190-8	49-91-41	AERO CONTROLEX	LUBE PUMP ASSY													
	3880190-9	49-91-41	AERO CONTROLEX	LUBE PUMP ASSY													
	3880193-1 INSPECT ONLY	49-91-41	AERO CONTROLEX	PLUG													
	3880200-6	49-27-15	ALLIED SIGNAL	SCAVENGE PUMP													
	3880271-1 INSPECT ONLY	49-91-41	AERO CONTROLEX	INDICATOR-DIFFERENTIAL PRESSURE													
	3880292-1 INSPECT ONLY	49-23-49	HONEYWELL	PRESSURE FITTING													
	3880305-2 INSPECT ONLY	49-23-49	HONEYWELL	VENT TUBE													
	3880326-10 INSPECT ONLY	49-27-15	HONEYWELL	GEAR SPUR ASSY													
	3880326-11 INSPECT ONLY	49-27-15	ALLIED SIGNAL	GEAR SHAFT													

	3880326-13 INSPECT ONLY	49-91-41	AERO CONTROLEX	GEAR SHAFT ASSY													
	3880614-14 INSPECT ONLY	49-91-41	AERO CONTROLEX	GEAR SPUR													
	3880614-17 INSPECT ONLY	49-91-41	AERO CONTROLEX	GEAR SPUR													
	3880927-1 INSPECT ONLY	49-91-41	HONEYWELL	CONTAINER													
	3880940-1 INSPECT ONLY	49-91-41	AERO CONTROLEX	GEAR SHAFT													
	3880942-1 INSPECT ONLY	49-91-41	AERO CONTROLEX	HOUSING													
	3880942-2 INSPECT ONLY	49-91-41	HONEYWELL	HOUSING SET													
	3880956-3 INSPECT ONLY	49-25-95	HONEYWELL	OIL IN TUBE													
	3880957-2 INSPECT ONLY	49-25-95	HONEYWELL	OIL OUT TUBE													
	3880958-1 INSPECT ONLY	49-25-95	HONEYWELL	OIL INLET SHIELD													
	3880959-1 INSPECT ONLY	49-25-95	HONEYWELL	OIL OUT SHIELD													
	3880981-1 INSPECT ONLY	49-91-41	AERO CONTROLEX	LUBE PUMP DRIVE SHAFT													
	3880993-1 TEST ONLY	49-91-49	HONEYWELL	PRESSURE RELIEF VALVE													
	3881000-2 3881000-4 3881000-5 3881000-6 3881000-7	49-91-49	AERO CONTROLEX	OIL PUMP ASSEMBLY													
	3881007-1 3881007-2 3881007-3 INSPECT ONLY	49-91-49	AERO CONTROLEX	ROTOR SET													
	3881008-2 INSPECT ONLY	49-91-49	AERO CONTROLEX	PLATE PORT													
	3881009-2 INSPECT ONLY	49-91-49	AERO CONTROLEX	PLATE PORT													
	3881010-2 INSPECT ONLY	49-91-49	AERO CONTROLEX	PLATE PORT													
	3881011-2 INSPECT ONLY	49-91-49	AERO CONTROLEX	PLATE PORT													
	3881012-2 INSPECT ONLY	49-91-49	AERO CONTROLEX	PLATE PORT													
	3881013-2 INSPECT ONLY	49-91-49	AERO CONTROLEX	PLATE PORT													
	3881017-1 INSPECT ONLY	49-91-49	HONEYWELL	FILTER HOUSING													
	3881018-1 INSPECT ONLY	49-91-49	HONEYWELL	RETAINER VALVE													
	3881051-1 INSPECT ONLY	49-23-49	HONEYWELL	OIL TRANSFER TUBE													
	3881052-1 TEST ONLY	49-91-49	AERO CONTROLEX	DIFFERENTIAL PRESSURE INDICATOR													
	3881059-1 INSPECT ONLY	49-91-49	HONEYWELL	TRANSFER TUBE													
	3881060-1 INSPECT ONLY	49-91-49	HONEYWELL	TRANSFER TUBE													

	3881061-1 INSPECT ONLY	49-91-49	AERO CONTROLEX	RETAINER TUBE												
	3881249-1 INSPECT ONLY	49-25-95	HONEYWELL	RING SEAL												
	3881691-1	49-91-49	AERO CONTROLEX	PUMP BYPASS VALVE												
	3881788-1	49-26-85	HONEYWELL	SHIELD-OIL COOLER												
	3882490-3 INSPECT ONLY	49-31-61	HONEYWELL	CARRIER ASSEMBLY SEAL												
	3882500-X	49-31-61	HONEYWELL	FUEL CONTROL ASSY												
	3882505-2 INSPECT ONLY	49-31-61	HONEYWELL	FUEL HOUSING ASSEMBLY												
	3882506-5 3882506-6 TEST ONLY	49-31-61	HONEYWELL	TORQUE MOTOR												
	3882511-1 INSPECT ONLY	49-31-61	HONEYWELL	FUEL TRANSFER ADAPTER												
	3882516-2 INSPECT ONLY	49-91-41	AERO CONTROLEX	COUPLING												
	3882545-1 INSPECT ONLY	49-31-61	HONEYWELL	RETAINER												
	3882547-3 INSPECT ONLY	49-31-61	AERO CONTROLEX	VALVE, MATCHED SET												
	3882550-3	49-31-63	HONEYWELL	FLOW DIVIDER												
	3882639-1 3882639-2 3882639-3	49-31-59	ALLIED SIGNAL	FUEL CHECK VALVE												
	3882639-4 3882639-5 TEST ONLY	49-31-59	ALLIED SIGNAL	FUEL CHECK VALVE												
	3882698-1 INSPECT ONLY	49-31-61	HONEYWELL	SPUR DRIVEN GEAR SHAFT												
	3883240-X	49-31-65	HONEYWELL	FUEL CONTROL ASSEMBLY												
	3883255-3 TEST ONLY	49-31-65	HONEYWELL	TORQUE MOTOR												
	3883255-4 TEST ONLY	49-31-65	HONEYWELL	TORQUE MOTOR												
	3883297-7	49-31-67	HONEYWELL	FUEL FLOW DIVIDER												
	3883499-1 3883499-2 3883499-3 B55690-2 B55690-3 B55690-004 B55690-005	49-50-05	HONEYWELL HONEYWELL HONEYWELL MOOG MOOG MOOG MOOG	SERVOACTUATOR												
	3883839-1 3883839-2	49-32-13	HONEYWELL	FUEL NOZZLE												
	3884211-1 INSPECT ONLY	49-23-49	HONEYWELL	SURGE ELBOW DUCT												
	3884238-3 INSPECT ONLY	49-23-49	HONEYWELL	TEE DUCT												
	3884391-1 INSPECT ONLY	49-23-49	HONEYWELL	SURGE AIR DUCT												
	3884647-1 TEST ONLY	49-25-95	HONEYWELL	LOAD COMPRESSOR ASSY												
	3884654-6 INSPECT ONLY	49-25-95	HONEYWELL	TEE DUCT												
	3884703-6 INSPECT ONLY	49-52-37	HONEYWELL	RETAINER SEAL												

	3884725-1 INSPECT ONLY	49-26-51	HONEYWELL	FAN INLET DUCT													
	3884971-1 TEST ONLY	49-26-85	HONEYWELL	TOTAL PRESSURE PROBE ASSY													
	3886167-2	49-50-03	HONEYWELL	SERVO ACTUATOR ASSY													
	3886167-3	49-50-03	HONEYWELL	SERVO ACTUATOR ASSY													
	3886167-4	49-50-03	HONEYWELL	SERVO ACTUATOR ASSY													
	3886169-1 3886169-2	49-50-04	HONEYWELL	SERVO ACTUATOR ASSEMBLY													
	3886188-1 3886188-2 3886188-3 TEST ONLY	49-50-07	HONEYWELL MOOG	IGV ACTUATOR													
	3888053-1 INSPECT ONLY	49-23-49	HONEYWELL	IGNITOR ADAPTOR													
	3888058-7	49-41-01	HONEYWELL	EXCITER													
	3888076-3 TEST ONLY	49-41-05	HONEYWELL	IGNITOR PLUG LEAD													
	3888217-4	49-41-10	HONEYWELL	ENGINE STARTER MOTOR													
	3888297-1	49-25-95	HONEYWELL	WIRING HARNESS ASSY													
	3888297-2	49-25-95	HONEYWELL	WIRING HARNESS ASSY													
	3888297-3	49-25-95	HONEYWELL	WIRING HARNESS ASSY													
	3888438-1	49-11-13	HONEYWELL	WIRING HARNESS ASSY													
	394408-8-1	73-10-17	ALLIED SIGNAL	FLOW DIVIDER VALVE													
	394408-9-1	73-10-17	ALLIED SIGNAL	FLOW DIVIDER VALVE													
	4100837G	49-53-02	PRATT & WHITNEY	BLEED CONTROL VALVE													
	4131020-1 4131020-2 4131020-3 4131020-4	49-90-57	HONEYWELL	LUBE MODULE													
	4132004-1 INSPECT ONLY	49-90-57	HONEYWELL	CAP VALVE													
	4132092-1 4132092-2 INSPECT ONLY	49-90-57	HONEYWELL	SCREEN													
	4132093-1 INSPECT ONLY	49-90-57	HONEYWELL	SHAFT OIL PUMP DRIVE													
	4132096-1 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132097-1 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132098-1 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132100-1 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132101-1 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132110-4 INSPECT ONLY	49-90-57	HONEYWELL	ROTOR													
	4132136-1 INSPECT ONLY	49-90-57	HONEYWELL	VALVE ASSY													
	4132151-3 INSPECT ONLY	49-90-57	HONEYWELL	HOUSING													

	4132152-3 INSPECT ONLY	49-90-57	HONEYWELL	SHAFT DRIVE													
	4132155-1 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132156-2	49-90-57	HONEYWELL	ROTOR RING													
	4132157-1 INSPECT ONLY	49-90-57	HONEYWELL	PLATE SEAL													
	4132159-2 INSPECT ONLY	49-90-57	AERO CONTROLEX	FILTER HOUSING													
	4132160-2 4132160-3 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132161-1 INSPECT ONLY	49-90-57	HONEYWELL	PLUG													
	4132164-1 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132165-1 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132166-1 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132166-2 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132167-1 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132168-1 4132168-3 INSPECT ONLY	49-90-57	HONEYWELL	PORTPLATE													
	4132169-1 4132169-2 INSPECT ONLY	49-90-57	HONEYWELL	PORT PLATE													
	4132202-3 4132202-4 INSPECT ONLY	49-90-57	HONEYWELL	FILTER HOUSING													
	4132218-1 4132218-3 INSPECT ONLY	49-90-57	HONEYWELL	PIN													
	4141028-1 4141028-2 4141028-3 4141028-4	49-90-55	HONEYWELL	DE PRIME VALVE													
	4300-7 TEST ONLY	29-00-02	FOKKER	SWITCH													
	43925	74-11-01	UNISON	EXCITER													
	4407017 TEST ONLY	49-91-49	AERO CONTROLEX	INDICATOR													
	4414020 INSPECT ONLY	49-91-49	HONEYWELL	FILTER HOUSING													
	441921-5	49-30-99	HONEYWELL	FUEL CONTROL													
	44760 TEST ONLY	74-10-44	UNISON	IGNITION EXCITER													
	4500039	49-32-04	P&WC	FUEL CONTROL ASSY													
	4501230A	APS3200 CIR	HAMILTON SUNDSTRAND	FUEL NOZZLE													
	4501259A	49-33-01	HAMILTON SUNDSTRAND	FLOW DIVIDER													
	4501259C	49-33-01	HAMILTON SUNDSTRAND	FLOW DIVIDER													
	4501788A INSPECT ONLY	APS3200 CIR	PRATT & WHITNEY	AIR DUCT ASSEMBLY													

	4502023 TEST/REPAIR	49-10-04	P&WC	ENGINE CONTROL HARNESS ASSY													
	4504086 TEST ONLY	49-23-05	P&W	ACTUATOR													
	4504400 TEST ONLY	APS3200 EM	P&WC	REAR BEARING HOUSING													
	4506061 TEST ONLY	49-10-06	APIC	WIRE HARNESS ASSY													
	4508693	49-70-05	HAMILTON SUNDSTRAND	IDENTIFICATION ASSEMBLY													
	4510835 TEST ONLY	49-23-05	P&WC	ACTUATOR													
	47649 1A7908	74-11-02	UNISON P&WC	IGNITION EXCITER													
	47649-1 1A7908	74-11-02	UNISON P&WC	IGNITION EXCITER													
	47649-2 1B7880	74-11-02	UNISON P&WC	IGNITION EXCITER													
	47649-3 1B7880	74-11-02	UNISON P&WC	IGNITION EXCITER													
	48378-2-4	49-20-14	HONEYWELL	ENGINE STARTER MOTOR													
	4900312 INSPECT ONLY	49-52-04	HAMILTON SUNDSTRAND	SEAL ASSEMBLY													
	4900314 INSPECT ONLY	49-52-04	HAMILTON SUNDSTRAND	BEARING													
	4950009 TEST ONLY	APS3200 EM	P&WC	SPEED SENSOR													
	4950014 TEST ONLY	APS3200 EM	P&WC	COMPRESSOR AIR TEMP SENSOR													
	4950036 TEST ONLY	APS3200 EM	P&WC	PRESSURE/ TEMP TRANSDUCER													
	4950488 TEST ONLY	APS3200 EM	P&WC	LOW OIL PRESSURE SWITCH													
	4950581-1 TEST ONLY	49-42-05	P&WC	IGNITION CABLE													
	4950581-2 TEST ONLY	49-42-05	P&WC	IGNITION CABLE													
	4950597-1 4950597-2	APS3200 EM	P&WC	THERMOCOUPLE													
	4951546 TEST ONLY	APS3200 EM	P&WC	COMPRESSOR DISCHARGE PRESSURE SENSOR													
	4951593 TEST ONLY	APS3200 CIR	P&WC	PRESSURE RELIEF VALVE													
	4951985 TEST ONLY	APS3200 EM	P&WC	LOW PRESSURE SWITCH													
	4951989 TEST/INSPECT ONLY	APS3200 CIR	P&WC	FLEXLINE, GEARBOX TO LOP SWITCH													
	4952164	49-41-07	UTC AEROSPACE	STARTER													
	49522 6895573 TEST ONLY	74-10-04	UNISON ROLLS-ROYCE	EXCITER													
	4952590 TEST ONLY	APS3200 EM	P&WC	SENSOR													
	4953795-1 TEST ONLY	APS3200 EM	P&WC	IGNITION CABLE													
	4953795-2 TEST ONLY	APS3200 EM	P&WC	IGNITION CABLE													
	4954220 TEST ONLY	APS3200 EM	P&WC	LOW OIL PRESURE SWITCH													
	49731	74-10-44	UNISON	IGNITION EXCITER													
	519852-X	49-44-02	HONEYWELL	ENGINE STARTER MOTOR													
	519858-8	49-41-22	HONEYWELL	ENGINE STARTER MOTOR													

	5908661 INSPECT ONLY	APS3200 CIR	P&WC	SCAVENGE PUMP ASSEMBLY													
	5908954 TEST ONLY	APS3200 EM	P&WC	SWITCH INDICATOR													
	5909073 TEST ONLY	APS3200 EM	P&WC	OIL TEMPERATURE SENSOR													
	5909849 TEST ONLY	APS3200 EM	P&WC	OIL LEVEL SENSOR													
	61163	28-20-18	EATON	FUEL SHUT OFF VALVE													
	6430589-1	24-21-14	HONEYWELL	PLATE SEAL													
	692545-1	49-30-67	HONEYWELL	SOLENOID SHUT OFF VALVE													
	692545-10	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-11	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-12	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-13	49-30-67	HONEYWELL	SOLENOID SHUT OFF VALVE													
	692545-17	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-18	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-2	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-3	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-400	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-500	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-6	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-7	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692545-9	49-30-67	HONEYWELL	SOLENOID SHUTOFF VALVE													
	692546-4 TEST ONLY	49-26-85	HONEYWELL	SOLENOID VALVE													
	715201-4	49-30-01	ARGO TECH	FUEL PUMP ASSY													
	75076-ALL	49-30-38	HONEYWELL	FUEL ATOMIZER ASSEMBLY													
	756671	APS3200 CIR	PRATT & WHITNEY	BEARING													
	756722 756722A 756722B	49-92-01	HAMILTON SUNDSTRAND	SOLENOID VALVE ASSEMBLY													
	76133 INSPECT ONLY	49-91-41	AERO CONTROLEX	FILTER HOUSING													
	7900013	38-30-08	ZODIAC	WASTE TANK ASSEMBLY													
	7900064	38-30-15	ZODIAC	VACUUM TOILET ASSEMBLY													
	7900071	38-30-08	ZODIAC	WASTE TANK ASSEMBLY													
	83311-49930 TEST ONLY	74-10-01	BF GOODRICH	EXCITER													
	856LU1 TEST ONLY	34-10-66	UTC AEROSPACE	PITOT TUBE													
	869169-1 TEST ONLY	72-IR-15	HONEYWELL	SENSOR, INLET TEMP/PRESSURE													
	869245-4	72-13-04	ALLIED SIGNAL	FEATHRING VALVE ASSY													
	884650-2 INSPECT ONLY	49-53-67	HONEYWELL	PLATE SEALING RING													

	8921082G1	38-10-01	BF GOODRICH	LAVATORY WATER HEATER												
	8921082G2	38-10-01	BF GOODRICH	LAVATORY WATER HEATER												
	8921082G5	38-10-01	BF GOODRICH	LAVATORY WATER HEATER												
	8921082G6	38-10-01	BF GOODRICH	LAVATORY WATER HEATER												
	897260-5 TEST ONLY	72-IR-10	HONEYWELL	PRESSURE RATION TRANSDUCER												
	897331-1 REPAIR ONLY	RS-101000	ALLIED SIGNAL	TRANSDUCER												
	897331-2 REPAIR ONLY	RS-101000	ALLIED SIGNAL	TRANSDUCER												
	897331-3 REPAIR ONLY	RS-101000	ALLIED SIGNAL	TRANSDUCER												
	897331-4 REPAIR ONLY	RS-101000	ALLIED SIGNAL	PRESSURE TRANSDUCER												
	897331-5 REPAIR ONLY	RS-101000	ALLIED SIGNAL	TRANSDUCER												
	899981-ALL	49-30-38	HONEYWELL	FUEL ATOMIZER ASSEMBLY												
	9040960-1 3876129-1	49-41-09	UNISON HONEYWELL	EXCITER												
	9043105-4 TEST ONLY	74-21-08	UNISON	IGNITION LEAD												
	9043185-16 9339M26P16	74-21-12	UNSION CFM INTERNATIONAL SA	IGNITION LEAD												
	9045000-1 804765	74-11-05	UNISON P&WC	EXCITER												
	■ 9045330-2	74-11-38	UNISON	EXCITER												
	■ 9048700-7 3876195-7	49-41-21	UNISON HONEYWELL	EXCITER												
	■ 9048700-8 3876195-8	49-41-21	UNISON HONEYWELL	EXCITER												
	■ 9048700-9 3876195-9	49-41-21	UNISON HONEYWELL	EXCITER												
	9048900-2 179420-2	49-42-01	UNISON HAMILTON SUNDSTRAND	IGNITION EXCITER												
	9049000-1 4950000	49-42-01	UNISON HAMILTON SUNDSTRAND	EXCITER												
	9049300-2 3888000-7	49-40-41	UNISON HONEYWELL	EXCITER												
	9049400-1 3039609	74-12-06	UNISON P&WC	IGNITION EXCITER												
	■ 9049800-4 3041640-01 TEST ONLY	74-12-09	UNISON P&WC	IGNITION EXCITER												
	9049860-1 3876280-1	49-41-25	UNISON HONEYWELL	EXCITER												
	9049860-10 3876280-4	49-27-23	UNISON P&WC	EXCITER												
	979786-1 979786-2 979786-4 979786-5 979786-6 OVERHAUL	49-50-65	HONEYWELL	SHUT OFF VALVE												
	979806-12	49-53-67	HONEYWELL	SURGE CONTROL VALVE 4"												
	9910331-1 GULTON UNITS REPAIR ONLY	RS-101000	CESSNA	TRANSDUCER												
	9910331-2	RS-101000	CESSNA	TRANSDUCER												
	9910331-3 REPAIR ONLY	RS-101000	CESSNA	TRANSDUCER												
	9910331-4 REPAIR ONLY	RS-101000	CESSNA	TRANSDUCER												

	9910331-5 REPAIR ONLY	RS-101000	CESSNA	TRANSDUCER												
	■ A64847-006 TEST ONLY	49-50-03	MOOG	SERVO ACTUATOR ASSY												
	■ A64847-007 TEST ONLY	49-50-03	MOOG	SERVO ACTUATOR ASSY												
	■ A64847-1 TEST ONLY	49-50-03	MOOG	SERVO ACTUATOR ASSY												
	■ A64847-2 TEST ONLY	49-50-03	MOOG	SERVO ACTUATOR ASSY												
	■ A64847-3 TEST ONLY	49-50-03	MOOG	SERVO ACTUATOR ASSY												
	A64847-4 TEST ONLY	49-50-03	MOOG	SERVO ACTUATOR ASSY												
	A64847-5 TEST ONLY	49-50-03	MOOG	SERVO ACTUATOR ASSY												
	A64982-ALL TEST ONLY	49-50-04	MOOG	SERVO ACTUATOR ASSEMBLY												
	CGFT1100-01	26-11-21	SIEMENS	SMOKE DETECTOR												
	L963046 430107	74-11-02	UNISON ROLLS-ROYCE	EXCITER												
	S685-1-11	31-09-45	WESTON AEROSPACE	THERMOCOUPLE HARNESS												
	S685-2-13	31-09-45	WESTON AEROSPACE	THERMOCOUPLE HARNESS												
	TGLN-2127	L-1106	UNISON	EXCITER												
	WE3888439-1	49-41-09	HONEYWELL	EXCITER												